

Integral Blinds Size Guide

X: Not possible ✓: Possible

🔥: The feeling of lifting is extremely heavy



MM	230-299	300-399	400-499	500-599	600-718	719-799	800-899	900-1067	1068-1099	1100-1199	1200-1299	1300-1399	1400-1417
240-299	X	X	X	X	X	X	X	X	X	X	X	X	X
300-399	X	X	X	X	X	X	X	X	X	X	X	X	X
400-499	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
500-599	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
600-699	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
700-799	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
800-899	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
900-999	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
1000-1099	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
1100-1199	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
1200-1299	✓	✓	✓	✓	✓	✓	✓	🔥	🔥	🔥	🔥	🔥	🔥
1400-1499	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X	X	X
1500-1599	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X	X	X
1600-1699	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X	X	X
1700-1799	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X	X	X
1800-1899	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X	X	X
1900-1999	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X	X	X
2000-2099	✓	✓	✓	✓	✓	X	X	X	X	X	X	X	X
2100-2199	✓	✓	✓	✓	✓	X	X	X	X	X	X	X	X
2200-2299	✓	✓	✓	✓	✓	X	X	X	X	X	X	X	X
2300-2399	✓	✓	✓	✓	✓	X	X	X	X	X	X	X	X
2400-2499	✓	✓	✓	✓	✓	X	X	X	X	X	X	X	X